



1. Determination of the number of airbag webs

The number of airbag webs should be detected on a reference background. For the tests a laser displacement sensor type **L-LAS-LT-37** is used. The measurement range of the laser sensor is around 4 mm and the reference distance of the sensor to the object is about 37 mm. The screenshots shows proper results.

