

### 1. Determination of the number of airbag webs

The number of airbag webs should be detected on a reference background.

For the tests a laser displacement sensor type **L-LAS-LT-37** is used.

The measurement range of the laser sensor is around 4 mm and the reference distance of the sensor to the object is about 37 mm.

The screenshots shows proper results.

